

**MY BOARD IS HERE!!
I THINK I HAVE FORGOTTEN EVERYTHING FROM
SUMMER TRAINING!! WHERE DO I START?**




First Steps:

1. Turn on your computer.
2. Turn on your document camera.
3. Using the remote, turn on your projector.


Once everything is on you are ready to have some fun with the board!!

Next Steps:

1. Find the ActivInspire icon. 
2. Double Click on the icon to open the program.
3. Once the program is open you are ready to use your board.




Begin by using the resources you already have on your computer.

To find things on your computer when you are in ActivInspire,
click on the Desktop Annotate icon. 

This will take you to your desktop and you can find anything on
your computer the way you normally would.



Your Remote Is Important.....Don't lose it.



The freeze button on the remote is also a handy tool. Use freeze to hold the image on the screen. When you go to your computer and do something like take attendance or check your email the students will continue to see what is projecting on the board.

If you want to hide your screen for a few minutes, use your remote and press "no show". The screen will go to black without turning off your projector. Use this feature when you want to check your email or you want to take attention off the board while you are talking.

To Use Your Document Camera:

1. Find the SDP850DX USB Viewer icon located on your desktop
2. Double click the icon
3. The following image will appear. Whatever is under your document camera will appear in the window.



4. Select SCREEN FULL
5. To adjust the zoom or brightness of the image, use the black document camera remote or the buttons on the base of the document camera. Use tele to zoom in closer and wide to zoom back out.

To exit the program:

1. Once the image has been enabled to full screen, close the program by clicking in the top right corner area of the image field. The following menu box will appear. (Note: The menu box will disappear if a selection is not made within a few seconds. If this occurs, just click the top right corner again.)



2. Select HALF
This will take the document camera out of full screen mode.
3. Select X to exit the document camera viewer.

